



1. Disconnect from mains.
2. Open the enclosure.
3. Remove the screws.
4. Disconnect the connection of LED light source.
5. Take out the LED light source.
6. Remove the lens on LED chips.
7. Take out the LED light source and LED driver.